PROBLEM SOLVING GUIDE

Organic Stains

Including, but not limited to bark, bird droppings, food, dirt, leaves and tobacco.

OPTIONS	STEPS
DEEP CLEANER  **COVERAGE** **33 TO 100** **SQ. FT. PER** **32 OZ.**	1. SWEEP OR VACUUM SURFACE TO BE CLEANED TO REMOVE ANY LOOSE CONTAMINANTS. 2. APPLY **DEEP CLEANER** LIBERALLY WITH TRIGGER SPRAY BOTTLE ON THE SURFACE TO BE CLEANED. MAKE SURE TO FULLY WET THE SURFACE. 3. ALLOW **DEEP CLEANER** TO DWELL ON SURFACE FOR 5 -10 MINUTES. PRODUCT SHOULD NOT DRY ON THE SURFACE. **EXPERT TIP:** IF NEEDED, SIMPLY SPRAY ADDITIONAL PRODUCT ON THE SURFACE TO KEEP WET. 4. AGITATE WITH A PRIMO TOOLS™ WHITE NYLON SCRUB PAD OR OTHER COMPARABLE NON-MARRING SCRUBBING TOOL UNTIL SURFACE IS CLEAN. 5. THOROUGHLY RINSE SURFACE WITH WATER. A WET/DRY VACUUM MAY ALSO BE USED. 6. SOME SURFACES MAY REQUIRE ADDITIONAL APPLICATIONS. 7. WIPE SURFACE COMPLETELY DRY USING A CLEAN, DRY, WHITE COTTON OR MICRO-FIBER TOWEL. 8. IF SURFACE IS TO BE SEALED, ALLOW 24 HOURS DRYING TIME PRIOR TO APPLYING A HIGH QUALITY OMNI SEALER.
HEAVY DUTY CLEANER  **COVERAGE** **200 TO 2,000** **SQ. FT. PER** **GALLON**	1. SWEEP OR VACUUM SURFACE TO BE CLEANED TO REMOVE ANY LOOSE CONTAMINANTS. 2. DILUTE **HEAVY DUTY CLEANER** WITH WATER TO MATCH CLEANING NEEDS: 1 PART TO 2 PARTS WATER – HEAVY DUTY; 1 PART TO 5 PARTS WATER – MEDIUM DUTY; 1 PART TO 40 PARTS WATER – LIGHT DUTY **EXPERT TIP:** WARM WATER ENHANCES **HEAVY DUTY CLEANER'S** PERFORMANCE. 3. LIBERALLY APPLY CLEANING SOLUTION TO THE SURFACE TO BE CLEANED WITH A SPONGAUSA™ SPONGE, OR A MOP OR BRUSH. 4. ALLOW CLEANING SOLUTION TO DWELL ON SURFACE FOR UP TO 5 MINUTES. 5. AGITATE WITH A PRIMO TOOLS™ WHITE NYLON SCRUB PAD OR A MOP, NATURAL-BRISTLE BRUSH OR OTHER COMPARABLE NON-MARRING SCRUBBING TOOL UNTIL SURFACE IS CLEAN. 6. MOP UP DIRTY SOLUTION. A WET/DRY VACUUM MAY ALSO BE USED. 7. THOROUGHLY RINSE SURFACE WITH WATER, CHANGING WATER AT LEAST EVERY 250 SQ. FT. 8. WIPE SURFACE COMPLETELY DRY USING A CLEAN, DRY, WHITE COTTON OR MICRO-FIBER TOWEL. 9. IF SURFACE IS TO BE SEALED, ALLOW 24 HOURS DRYING TIME PRIOR TO APPLYING A HIGH QUALITY OMNI SEALER.
ELITE CLEANER  **COVERAGE** **200 TO 2,000** **SQ. FT. PER** **GALLON**	1. SHAKE WELL BEFORE EACH USE. 2. SWEEP OR VACUUM SURFACE TO BE CLEANED TO REMOVE ANY LOOSE CONTAMINANTS. 3. APPLY **ELITE CLEANER** LIBERALLY ON SURFACE TO BE CLEANED DIRECTLY FROM BOTTLE OR WITH A SPONGAUSA™ SPONGE, OR A BRUSH OR SCRUB MACHINE. 4. ALLOW **ELITE CLEANER** TO DWELL ON SURFACE FOR UP TO 5 MINUTES. 5. AGITATE WITH A PRIMO TOOLS™ WHITE NYLON SCRUB PAD, OR A BRUSH OR OTHER COMPARABLE NON-MARRING SCRUBBING TOOL UNTIL CONTAMINATE OR STAIN IS REMOVED. 6. THOROUGHLY RINSE SURFACE WITH WATER. A WET/DRY VACUUM MAY ALSO BE USED. **EXPERT TIP:** HIGH-PRESSURE (1000–3000 PSI) SPRAYERS ARE HIGHLY EFFECTIVE AT RINSING AWAY CONTAMINATES AND STAINS WHEN USED IN CONJUNCTION WITH **ELITE CLEANER**. 7. WIPE SURFACE COMPLETELY DRY USING A CLEAN, DRY, WHITE COTTON OR MICRO-FIBER TOWEL. 8. IF SURFACE IS TO BE SEALED, ALLOW 24 HOURS DRYING TIME PRIOR TO APPLYING A HIGH QUALITY OMNI SEALER.

Technical Support: 949-709-5270 Mon thru Fri 6:00am PT to 4:00pm PT and/or E-mail TechSupport@OMNI-Sealers.com.

Problem Solving Guide is a general recommendation. Actual results may vary. Read product directions thoroughly before use.
ALWAYS TEST IN A SMALL INCONSPICUOUS AREA.